


Sensor Activated Clean Dry™ Hand Dryer



Item	Part	Description
1	THP3023WH	Front Cover
2	THP3024WH	Side Cover (left)
3	THP3025WH	Side Cover (right)
4	THP3026	Water Tray
5	THP3027	Filter
6	THP3028	Luminescent Sensor (left & right)
7	THP3029	Luminescent Sensor (center)
8	THP3030	Light Receiving Sensor

Item	Part	Description
9	THP3031	LED
10	THP3032	Controller Assy.
11	THP3033	Fan Motor Assy.
12	THP3034	Attaching Screw (1 ea.)
13	THP3035	Truss Head Tapping Screw (1 ea.)
14	THP3036	Special Tapping Screw (1 ea.)
15	THP3037	Base Plate
16	THP3052	Special Hex Wrench (Star/Pin)